

CF=Center Frequency
SW=Sweep range
SWR=SWR of CF

2. Turn knob
To change
The value of
the item with
the red
arrow



MEM=saved CF,SW
Green digits=battery voltage
Z: Impedance at CF

1. Push knob
to move arrow

3. To save settings, make sure you are on the MEM (memory) number you want to use, press and hold the knob until the SAVE message appears on the display

/home/lordbruce/Documents/Ham RARC/Equipment-loans/W4BRU-loan-FG-10-antenna-analyzer/YouKits-FG-01-antenna-analyzer-guide-by-W4BRU.odg